



Instruction Manual
CHAIN USB



Instruction Manual
CHAIN USB



EN

SYSTEM REQUIREMENTS

Computer Model:

IBM PC/AT compatible or Apple Macintosh, Power Macintosh, PowerBook, iMac or iBook.

OS:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, Windows 7, Linux kernel 2.6.17 or higher, Mac OS 9.0 or higher.

FR

CONFIGURATION REQUISE

Ordinateur:

Ordinateur compatible IBM PC/AT ou Apple Macintosh, Powerbook, iMac ou iBook.

Système d'exploitation:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, Windows 7, Linux kernel 2.6.17 ou ultérieur, Mac OS 9.0 ou ultérieur.

GE

SYSTEMVORAUSSETZUNGEN

Computermodell:

IBM PC/AT kompatibel oder Apple Macintosh, Power Macintosh, PowerBook, iMac oder iBook.

Betriebssystem:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, Windows 7, Linux Kernel 2.6.17 oder höher, Mac OS 9.0 oder höher.

NL

SYSTEEMVEREISTEN

Computer :

IBM PC/AT compatibel of Apple Macintosh, Power Macintosh, PowerBook, iMac of iBook.

OS:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, Windows 7, Linux kernel 2.6.17 of hoger, Mac OS 9.0 of hoger.

ES

REQUISITOS DEL SISTEMA

Modelo de ordenador:

IBM/PC AT compatible o Apple, Macintosh, Power Macintosh, PowerBook, iMac o iBook.

OS:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, Windows 7, Linux kernel 2.6.17 o posterior, Mac OS 9.0 o posterior.

IT

REQUISITI DI SISTEMA


Modello computer:

Compatibile con IBM PC/AT o Apple Macintosh, Power Macintosh, PowerBook, iMac o iBook.

Sistema Operativo:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, windows 7, Linux kernel 2.6.17 o versioni successive, Mac OS 9.0 o versioni successive.

Instruction Manual USB FLASH

**EN**

SYSTEM REQUIREMENTS

Computer Model:

IBM PC/AT compatible or Apple Macintosh, Power Macintosh, PowerBook, iMac or iBook.

OS:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, Windows 7, Linux kernel 2.6.17 or higher, Mac OS 9.0 or higher.

FR

CONFIGURATION REQUISE

Ordinateur:

Ordinateur compatible IBM PC/AT ou Apple Macintosh, Powerbook, iMac ou iBook.

Système d'exploitation:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, Windows 7, Linux kernel 2.6.17 ou ultérieur, Mac OS 9.0 ou ultérieur.

GE

SYSTEMVORAUSSETZUNGEN

Computermodell:

IBM PC/AT kompatibel oder Apple Macintosh, Power Macintosh, PowerBook, iMac oder iBook.

Betriebssystem:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, Windows 7, Linux Kernel 2.6.17 oder höher, Mac OS 9.0 oder höher.

NL

SYSTEEMVEREISTEN

Computer :

IBM PC/AT compatibel of Apple Macintosh, Power Macintosh, PowerBook, iMac of iBook.

OS:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, Windows 7, Linux kernel 2.6.17 of hoger, Mac OS 9.0 of hoger.

ES

REQUISITOS DEL SISTEMA

Modelo de ordenador:

IBM/PC AT compatible o Apple, Macintosh, Power Macintosh, PowerBook, iMac o iBook.

OS:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, Windows 7, Linux kernel 2.6.17 o posterior, Mac OS 9.0 o posterior.

IT

REQUISITI DI SISTEMA

Modello computer:

Compatibile con IBM PC/AT o Apple Macintosh, Power Macintosh, PowerBook, iMac o iBook.

Sistema Operativo:

Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP, Windows Vista, windows 7, Linux kernel 2.6.17 o versioni successive, Mac OS 9.0 o versioni successive.

Instruction Manual USB FLASH

